

# ADVANCE<sup>™</sup> WATERBORNE INTERIOR ALKYD SATIN 792

#### **Features**

- · Excellent durability
- Excellent flow and leveling properties
- · Extended open time
- · Spatter resistant
- Easy application
- · Easy clean up
- Block resistant

# **General Description**

A premium quality, waterborne alkyd enamel that delivers the desired flow and leveling characteristics of conventional alkyd paint. It provides a tough, satin finish that stands up to repeated washing. It is easy to apply, resists spattering and cleans up with soap and water.

# **Recommended For**

Ideal for interior trim, doors, walls, and ceilings. For primed or previously painted wallboard, plaster, masonry, wood and metal.

# Limitations

- Do not apply when air and surface temperatures are below 50° F (10° C).
- Depending on weather and drying conditions, it could take up to 30 days to reach optimum hardness and final sheen.

# **Product Information**

Colors — Standard:

White (01)

#### - Tint Bases:

Benjamin Moore® Gennex® Bases 1X, 2X, 3X, 4X

#### - Special Colors:

Contact your Benjamin Moore & Co. representative.

#### **Certification:**

#### VOC compliant in all regulated areas

Class A (0-25) over non-combustible surfaces when tested in accordance with ASTM E-84

CHIPS Certified (Collaboration for High Performance Schools) Qualifies for LEED<sup>®</sup> Credit (INTERIOR NON-FLAT)

#### **Technical Assistance:**

Available through your local authorized independent Benjamin Moore® retailer. For the location of the retailer nearest you, call 1-800-826-2623, see www.benjaminmoore.com, or consult your local Yellow Pages.

Technical Datao	Pastel Base
Vehicle Type	Waterborne alkyd
Pigment Type	Titanium Dioxide
Volume Solids	39%
Coverage per Gallon at Recommended Film Thickness	400 – 500 Sq. Ft.
Recommended Film — Wet Thickness — Dry	3.6 mils 1.35 mils

Depending on surface texture and porosity. Be sure to estimate the right amount of paint for the job. This will ensure color uniformity and minimize the disposal of excess paint. See chart on page two.

Dry Time @ 77° F	<ul><li>To Touch</li></ul>	4-6 Hours
(25° C) @ 50% RH	<ul> <li>To Recoat</li> </ul>	16 Hours

Advance's full hardness and adhesion develop over time. Do not expose to heavy abrasion or return shelves/tabletops to service for at least 3-5 days to prevent damage to the finish. High humidity or cooler temperatures will prolong dry, recoat and cure times.

Dries By		Evaporation, Oxidation
Viscosity		95 ± 5 KU
Flash Point		None
Gloss / Sheen		Satin (25-35 @ 60°)
Surface Temperature at Application	– Min. – Max	50° F 90° F
Thin With		Clean Water
Clean Up Thinner		Clean Water
Weight Per Gallon		10.9 lbs
Storage Temperature	– Min – Max	40° F 90° F

#### **Volatile Organic Compounds (VOC)**

48 Grams / Liter .40 LBS / Gallon

♦ Reported values are for Pastel Base. Contact Benjamin Moore & Co. for values of other bases or colors

# **Surface Preparation**

Surfaces to be painted must be clean, dry, and free of dirt, dust, grease, oil, soap, wax, scaling paint, water soluble materials, and mildew. Remove any peeling or scaling paint and sand these areas to feather edges smooth with adjacent surfaces. Glossy areas should be dulled. Drywall surfaces must be free of sanding dust.

New plaster or masonry surfaces must be allowed to cure before applying base coat. Cured plaster should be hard, have a slight sheen and maximum PH of 10; soft, porous or powdery plaster indicates improper cure. Never sand a plaster surface; knife off any protrusions and prime plaster before and after applying patching compound. Poured or pre-cast concrete with a very smooth surface should be etched or abraded to promote adhesion, after removing all form release agents and curing compounds. Remove any powder or loose particles before priming. Wood substrates must be thoroughly dry.

**Difficult Substrates:** Benjamin Moore offers a number of specialty primers for use over difficult substrates such as bleeding woods, grease stains, crayon markings, hard glossy surfaces, galvanized metal, or other substrates where paint adhesion or stain suppression is a particular problem. Your Benjamin Moore <sup>®</sup> retailer can recommend the right problem solving primer for your special needs.

WARNING! If you scrape, sand or remove old paint, you may release lead dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a NIOSH-approved respirator to control lead exposure. Carefully clean up with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by contacting the National Lead Information Hotline at 1-800-424-LEAD or log on to <a href="https://www.epa.gov/lead">www.epa.gov/lead</a>.

# **Primer/Finish Systems**

New surfaces should be fully primed, and previously painted surfaces may be primed or spot primed as necessary. For best hiding results use Benjamin Moore<sup>®</sup> Advance<sup>™</sup> Waterborne Interior Alkyd Primer tinted to the approximate finish coat color. Special Note: Certain custom colors require a Deep Color Base Primer tinted to a special prescription formula to achieve the desired color. Consult your retailer.

#### Wood and engineered wood products:

Primer: Advance ™ Waterborne Interior Alkyd Primer (790). Benjamin Moore® Fresh Start® All-Purpose 100% Acrylic Primer (023) or All-Purpose Alkyd Primer (024)

Finish: 1 or 2 coats Advance <sup>™</sup> Waterborne Interior Alkyd Satin (792)

Drywall:

**Primer:** Advance<sup>™</sup> Waterborne Interior Alkyd Primer (790)

Finish: 1 or 2 coats Advance <sup>™</sup> Waterborne Interior Alkyd Satin (792)

Plaster

Primer: Benjamin Moore® Fresh Start® All-Purpose 100% Acrylic Primer

(N023)

Finish: 1 or 2 coats Advance<sup>™</sup> Waterborne Interior Alkyd Satin (792)

Masonry; Rough or Pitted Masonry:

Primer: Super Spec® Masonry Latex Block Filler (160)

Finish: 1 or 2 coats Advance Waterborne Interior Alkyd Satin (792)

Masonry; Smooth Poured or Pre-cast Concrete:

**Primer:** Benjamin Moore® Fresh Start® All-Purpose 100% Acrylic Primer (N023)

Finish: 1 or 2 coats Advance<sup>™</sup> Waterborne Interior Alkyd Satin (792)

Unpainted Metal (Ferrous):

**Primer:** Super Spec HP<sup>®</sup> DTM Acrylic Low Lustre (P25) or Super Spec HP<sup>®</sup> DTM Alkyd Low Luster (P23)

Finish: 1 or 2 coats Advance Waterborne Interior Alkyd Satin (792)

Hard glossy alkyd surfaces: Abrasion by sanding leads to optimum adhesion.

**Galvanized Metal:** All new galvanized metal surfaces must be thoroughly cleaned with mineral spirits to remove contaminants.

**Primer:** Super Spec HP<sup>®</sup> DTM Acrylic Low Lustre (P25) or Super Spec HP<sup>®</sup> Acrylic Metal Primer (P04)

Finish: 1 or 2 coats Advance™ Waterborne Alkyd Satin (792)

**Repaint, All Substrates:** Prime bare areas with the primer recommended for the substrate above.

# **Application**

Stir thoroughly before and during use. Apply one or two coats. **Paint Application:** For best results, use a premium Benjamin Moore<sup>®</sup> custom-blended nylon/polyester brush, premium Benjamin Moore<sup>®</sup> Microfiber roller, or a similar product. Apply paint generously from unpainted area into wet area. This product can also be sprayed.

Extra ventilation is necessary under humid conditions to speed the dry time of Advance, especially when the paint is applied over sealed, hard, non-porous surfaces. The chart below is for general guidance.

general galacitee.				
Mild conditions	Severe conditions	Very severe conditions		
Dry (RH<50%), and Temperature between 70°F and 90°F	(RH> 50%), and/or temperature between 50°F and 70°F	RH> 85%, or temperature < 50°F		
Advance will dry normally. Dry to touch: 4-6 hours To Recoat: 16 hours	Advance will dry slower than normal unless the following is done to speed the dry time: Ventilate the room with a fan and/or turn on A/C to lower the humidity.	Do not apply Advance		

**Spray, Airless:** Fluid Pressure — 1,500 - 2,500 PSI;

Tip — .011 - .015 Orifice

#### Thinning/Cleanup

Thinning is unnecessary, but if required to obtain desired application properties, a small amount of clean water may be added. Never add other paints or solvents. Clean up with warm soapy water. Brushes and rollers should be given a final rinse with mineral spirits to remove residual alkyd. Spray equipment should be given a final rinse with mineral spirits to prevent rusting.

USE COMPLETELY OR DISPOSE OF PROPERLY. Dry, empty containers may be recycled in a can recycling program. Local disposal requirements vary; consult your sanitation department or state-designated environmental agency on disposal options.

#### **Environmental Health & Safety Information**

**Use only with adequate ventilation.** Do not breathe spray mist or sanding dust. Ensure fresh air entry during application and drying. Avoid contact with eyes and prolonged or repeated contact with skin. Avoid exposure to dust and spray mist by wearing a NIOSH approved respirator during application, sanding and clean up. Follow respirator manufacturer's directions for respirator use. Close container after each use. Wash thoroughly after handling.

**WARNING:** This product contains a chemical known to the state of California to cause cancer and birth defects, or other reproductive harm.

**FIRST AID**: In case of eye contact, flush immediately with plenty of water for at least 15 minutes; for skin, wash thoroughly with soap and water. If symptoms persist, seek medical attention. If you experience difficulty breathing, leave the area to obtain fresh air. If continued difficulty is experienced, get medical attention immediately.

**IN CASE OF SPILL** – Absorb with inert material and dispose of as specified under "Clean Up".

# KEEP OUT OF REACH OF CHILDREN PROTECT FROM FREEZING

Refer to Material Safety Data Sheet for additional health and safety information.

Benjamin Moore & Co., 101 Paragon Drive, Montvale, NJ 07645 Tel: (201) 573-9600 Fax: (201) 573-9046 www.benjaminmoore.com M72 0792 US 10/10